SETIPL Manual procedure

Step number	*Meaning*	*Sequence of events*	
1	This step sets an invalid instruction character (semicolon) in position 10 in partition core to enable single instruction execution.	LOAD CONDITION LOAD ENTRY 0001010001 ENTER ; LOAD CONDITION	This step may be omitted if DMF II partition low core is initialised.
2 3	This step sets the primary SYSRES volume indicator and the conversational-loader-idle switch in DMF II standard common.	LOAD CONDITION LOAD ENTRY 0039P10020 ENTER 000000040TU0PQ*dti*009 LOAD CONDITION	where *d* is the drive number (0 to 9) of the primary SYSRES volume to be used. *t* is 0 or 6; 6 only if a model 41B disc pack (the upper volume of a model 42 disc drive). *i* is the conversational-loader-idle switch (0 for initial startup mode, P for reconfiguration mode). This step is required only for initial startup mode and for reconfiguration mode.
2	CLEAR COMMON	LOAD CONDITION (LOADLOAL) LOAD ENTRY 1039P10T00 ENTER Φ	

7700/0

7700/0

3 4	This step sets the flag to A (available).	LOAD CONDITION LOAD ENTRY 0058P10001 ENTER A LOAD CONDITION	This step is required only if DMF II standard common is not initialised and the system mailbox availability flag (common location 0580) is set to B (busy).
4 5	This step sets a flag to indicate to the conversational loader that a single entry is to be accepted from an MTIOC device, using the primary SYSRES volume as the SYSRES volume of this partition.	LOAD CONDITION LOAD ENTRY 0030010002 ENTER =*m* LOAD CONDITION ? C (CANCEL JOBSTREAM)	where *m* is the number (in the range 0 to 9, but usually 0) of the MTIOC device which will provide the entry. This step and step 6 are the only entries required for partition mode operation.
5 6	This step causes an IPL, loading the conversational loader from the primary SYSRES volume.	LOAD CONDITION LOAD ENTRY E SYS (Press enter key)	