

Control characters for MTIOC devices

Device	Character	Definition
Card reader	?	Local query
Card-punch	_ (underscore) L or J ? N O	Punch unit separator Feed a card Local query Enter Minus Zero Mode Leave Minus Zero Mode
Line printer	/nn K L ? Z1 to Z<	Set Vertical Tab Register Advance paper Skip to top-of-form Local query Skip to VFU channel Zn (for Models 53 to 56 12-channel VFU tape option)
Magnetic tape	T R B F E M L L D	Write tape mark Rewind Backspace block Forwardspace block Erase Change mode Rewind and switch to Local Test Write Enable Ring

7700/0

Video display unit	O T R S ^ \ Y H J I L X ? G	Lock Unlock Initiate Block Mode Initiate Formatting Mode Cursor home Cursor up Cursor down Cursor right Cursor left New line Tab Erase all unprotected characters Erase Local query Sound alarm (Model 82)
Workstation (Model 70)	M H -fn /nn K Gx , () ?	Carriage return Backspace Load Horizontal Tab Register Horizontal Tab Load Vertical Tab Register Vertical Tab Illuminate indicator light (x defines pattern) Illuminate Repeat Entry Light Enter Non-Print Mode Leave Non-Print Mode Local query

7700/0